

Category	MAIN GROUPE
<u>1. ENGINE</u>	
1	1 ENGINE HOUSING
1	3 CRANK ASSEMBLY PARTS
1	5 ENGINE TIMING
1	9 AIR FILTER AND ENGINE CHARGING
1	14 INTAKE MANIFOLD AND EXHAUST MANIFOLD
1	18 ENGINE LUBRICATION
1	21 MAJOR ASSEMBLY DETACHABLE PARTS
1	22 ENGINE MOUNT
1	24 Engine/transmission suspension
1	25 Clutch
1	43 Engine brake
1	45 Belt tensioner
1	48 Oil container
<u>2. TRANSMISSION</u>	
2	27 AUTOMATIC TRANSMISSION
2	26 MANUAL TRANSMISSION
2	28 TRANSFER CASE
<u>3. HIGH-VOLTAGE COMPONENTS</u>	
3	8 ELECTRIC DRIVE / HYBRID DRIVE
<u>4. PEDAL ASSEMBLY</u>	
4	29 PEDAL ASSEMBLY
<u>5. SPRINGS, SUSPENSION AND HYDRAULIC COMPONENTS</u>	
5	32 SPRINGS, SUSPENSION AND HYDRAULIC COMPOI
<u>6. FRONT AXLE, STEERING</u>	
6	33 FRONT AXLE
6	46 STEERING
6	41 PROPELLER SHAFT
6	13 Power-steering pump
<u>7. REAR AXLE</u>	
7	35 REAR AXLE
7	41 PROPELLER SHAFT
7	39 Leading and trailing axle
<u>8. WHEELS</u>	
8	40 WHEELS
8	59 Tire pressure control system
<u>9. BRAKE SYSTEM</u>	
9	42 BRAKES
<u>10. FUEL SYSTEM</u>	
10	47 FUEL SYSTEM
10	7 FUEL INJECTION
	11 Gas regulator unit
<u>11. EXHAUST SYSTEM</u>	
11	49 EXHAUST SYSTEM

12. COOLING

12	20	ENGINE COOLING
12	50	COOLER

13. BODY PARTS

13	52	Engine compartment lining/air intake
13	60	BODY-IN-WHITE
13	61	SUBSTRUCTURE
13	62	FRONT-END ASSEMBLY, FRONT PANEL
13	63	SIDE WALLS
13	64	REAR END
13	65	ROOF
13	67	WINDOW SYSTEM
13	72	DRIVER'S DOOR
13	73	REAR DOORS
13	74	REAR-END DOOR
13	75	TRUNK LID
13	78	SLIDING SUNROOF
13	88	DETACHABLE PARTS
13	51	Firewall
13	66	Installation
13	71	Partition/load protection grille
13	76	Door operation
13	77	Soft top
13	79	Spoiler

14. ELECTRICAL SYSTEM

14	15	ENGINE ELECTRICAL SYSTEM
14	54	ELECTRICAL EQUIPMENT AND INSTRUMENTS
14	82	ELECTRICAL SYSTEM
14	86	WINDSHIELD WASHER SYSTEM, EMERGENCY EQ

15. TRIM

15	68	Instrument panel/center console/linings
15	69	TRIM AND LINING
15	81	Equipment-interior equipment

16. HEATING AND VENTILATION

16	83	HEATING AND VENTILATION
----	----	---

17. SEATING SYSTEM

17	91	DRIVER'S SEAT
17	92	REAR SEAT
17	93	Folding seat
17	94	Passenger seats, single-seater seat
17	95	Passenger seats, multi-seater chair
17	97	Seat accessories

18. TRAILER COUPLING

18	31	TRAILER COUPLING
----	----	----------------------------------

19. ACCESSORIES / SPECIAL EQUIPMENT

19	98	ACCESSORIES
----	----	-----------------------------

19	99 Retrofits
19	58 TOOLS AND ACCESSORIES
19	23 Special equipment
19	89 Vehicle accessories
20. Hydraulic system	
20	55 Hydraulic system
20	56 Cable winch
20	57 Central lubrication
20	80 Vacuum system / hydraulic system
21. PARTS PAGAGES	
21	0 MAINTENANCE
21	
21	
21	
21	
21	
21	
21	
21	
21	
21	
21	13 BELT DRIVE, AIR COMPRESSOR
21	
21	15 ELECTRICAL COMPONENTS, ENGINE
21	
21	
21	20 ENGINE COOLING
21	
21	
21	25 CLUTCH
21	32 SUSPENSION, DAMPER
21	
21	
21	33 FRONT AXLE
21	
21	
21	
21	
21	
21	40 WHEEL, MEASUREMENTS
21	42 BRAKES, MECHANICAL, HYDRAULIC
21	
21	
21	
21	

21	
21	46 STEERING
21	
21	47 FUEL SYSTEM
21	
21	49 EXHAUST SYSTEM, GAS CLEANING
21	54 ELECTRICAL EQUIPMENT AND INSTRUMENTS
21	
21	82 ELECTRICAL SYSTEM
21	
21	
21	
21	
21	
21	
21	67 WINDOW
21	
21	82 ELECTRICAL WIRING; RADIO
21	83 HEATER, VENTILATION, AC
21	
21	88 VEHICLE DETACHABLE PARTS
21	
21	

22. PAINT & OPERATING FLUIDS

22	10 TOUCH-UP PENCILS
22	11 SPRAY CANS
22	13 ADHESIVES / PRIMER
22	14 BODY REPAIR WORK MATERIAL
22	17 SEALING COMPOUND
22	18 ENGINE OIL
22	19 SEALING TAPES / CORDS
22	20 ENGINE COOLING SERVICE MATERIAL
22	21 EXTERIOR CAR CARE
22	22 INTERIOR CAR CARE
22	24 GRAISSES / PASTES
22	26 GEAR OIL / HYDRAULIC OIL
22	35 REAR AXLE
22	42 BRAKES SERVICE MATERIAL
22	47 FUEL SYSTEM SERVICE MATERIAL
22	49 EXHAUST SYSTEM SERVICE MATERIAL
22	54 ELECTROLYTES AND ELECT. LINE
22	58 TOOLS AND ACCESSORIES
22	67 WINDOW INSTALLATION SERVICE MATERIAL
22	72 DOORS
22	77 SERVICE: CONVERTIBLE TOP / SUNROOF
22	83 AIR CONDITIONING SERVICE MATERIAL

22
22


86 [WINDSHIELD WASHER SYSTEM SERVICE MATERI/](#)
92 [TARPAULINS](#)




Internal

SUBGROUP

[NENTS](#)



[JIPMENT](#)



Service A

Service B

Replace vehicle dust filter

Replace TIREFIT

Replace air cleaner element

Replace brake fluid

Replace spark plugs

Replace battery in KEYLESS-GO transmitter key

Oil service in automatic transmission

Oil service in the automatic transmission and transfer case

Replace V-belt On veh. with single-belt drive

Replace Alternator

Replace Starter

Replace electric coolant pump

Replace coolant including antifreeze

Replace 2 shock absorbers of rear axle

Replace 2 front suspension struts

Replace right spring control arm for front axle

Replace left spring control arm for front axle

Replace both front spring control arms

Replace left strut rod of front axle

Replace right strut rod of front axle

Fluid in hydraulic brake system replace

Replace brake pads of front axle, Floating brake caliper

Replace brake pads of rear axle

Repl. brake pads of front and rear axle, with wheels rem., Floating brake caliper

Replace front brake pads and disks, Floating brake caliper

Internal

Replace brake pads and disks of rear axle

Power steering Exchange

Replace fuel pump On veh. with W&G package

Replace on-board electrical system battery (After check)

Replace left front lamp unit

Light unit at right front replace

Left rear light unit replace

Right rear light unit replace

Replace 2 wiper blades for front window


Replace wiper blade for rear window


Replace windshield

A/C evaporator Clean

Replace left glass for exterior rear-view mirror

Replace right glass for exterior rear-view mirror





Kategorie

Hauptgruppe

1. MOTOR

- 1 [MOTORGEHÄUSE](#)
- 3 [TRIEBWERKTEILE](#)
- 5 [MOTORSTEUERUNG](#)
- 9 [LUFTFILTER UND MOTORAUFLADUNG](#)
- 14 [SAUGROHR UND AUSPUFFKRÜMMER](#)
- 18 [MOTORSCHMIERUNG](#)
- 21 [MAJOR ASSEMBLY DETACHABLE PARTS](#)
- 22 [MOTORAUFHÄNGUNG](#)
- 24 [Motor- / Getriebeaufhängung](#)
- 25 [Kupplung](#)
- 43 [Motorbremse](#)
- 45 [Riemenspanner](#)
- 48 [Ölbehälter](#)

2. GETRIEBE

- 27 [AUTOMATISCHES GETRIEBE](#)
- 26 [MECHANISCHES GETRIEBE](#)
- 28 [VERTEILERGETRIEBE](#)

3. HOCHVOLT KOMPONENTEN

- 8 [Elektroantrieb / Hybridantrieb](#)

4. PEDAL ASSEMBLY

- 29 [PEDALANLAGE](#)

5. FEDERN, AUFHÄNGUNG UND HYDRAULIK

- 32 [FEDERN, AUFHÄNGUNG UND HYDRAULIK](#)

6. VORDERACHSE, LENKUNG

- 33 [VORDERACHSE](#)
- 46 [LENKUNG](#)
- 41 [GELENKWELLE](#)
- 13 [Lenkhelfpumpe](#)

7. HINTERACHSE

- 35 [HINTERACHSE](#)
- 41 [GELENKWELLE](#)
- 39 [Vorlauf- und Nachlaufachse](#)

8. RÄDER

- 40 [RÄDER](#)
- 58 [Reifendruckregelanlage](#)

9. BREMSYSTEM

- 42 [BREMSSEN](#)

10. KRAFTSTOFFANLAGE

- 47 [KRAFTSTOFFANLAGE](#)
- 7 [KRAFTSTOFFEINPRITZUNG](#)
- 11 [Gasregeleinheit](#)

11. AUSPUFFANLAGE

- 49 [AUSPUFFANLAGE](#)

12. KÜHLUNG

13. KARROSSERIETEILE

14. ELEKTRISCHE ANLAGE

15. VERKLEIDUNG

16. HEIZUNG UND KLIMAANLAGE

17. SITZANLAGE

18. ANHÄNGERKUPPLUNG

19. ZUBEHÖR / SONDEREINBAUTEN

20 [MOTORKÜHLUNG](#)

50 [KÜHLER](#)

52 [Motorraumverkleidung / Luftansaugung](#)

60 [ROHBAU](#)

61 [UNTERBAU](#)

62 [VORBAU, VORDERWAND](#)

63 [SEITENWÄNDE](#)

64 [HECK](#)

65 [DACH](#)

67 [FENSTERANLAGE](#)

72 [FAHRERTÜREN](#)

73 [FONDTÜREN](#)

74 [RÜCKWANDTÜR](#)

75 [HECKDECKEL](#)

78 [SCHIEBEDACH](#)

88 [ANBAUTEILE](#)

51 [Stirnwand](#)

66 [Einbauten](#)

71 [Trennwand / Lastschutzgitter](#)

76 [Türbetätigung](#)

77 [Verdeck](#)

79 [Spoiler](#)

15 [MOTORELEKTRIK](#)

54 [ELEKTRISCHE AUSRÜSTUNG UND INSTRUMENTE](#)

82 [ELEKTRISCHE ANLAGE](#)

86 [SCHEIBENWASCHANLAGE](#)

68 [Instrumententafel / Mittelkonsole / Beläge](#)

69 [VERKLEIDUNG UND AUSSCHLAG](#)

81 [Ausstattung-Inneneinrichtung](#)

83 [HEIZUNG UND KLIMAANLAGE](#)

91 [FAHRERSITZ](#)

92 [FONDSITZ](#)

93 [Klappsitz](#)

94 [Fahrgastsitze, Einsitzerstuhl](#)

95 [Fahrgastsitze, Mehrsitzerstuhl](#)

97 [Sitzzubehör](#)

31 [ANHÄNGERKUPPLUNG](#)

98 [ZUBEHÖR](#)

20. Hydraulikanlage

21. TEILEPAKETE

- 99 [Nachrüstung](#)
- 58 [WERKZEUG UND ZUBEHÖR](#)
- 23 [Sondereinbauten](#)
- 89 [Fahrzeug-Zubehör](#)
- 55 [Hydraulikanlage](#)
- 56 [Seilwinde](#)
- 57 [Zentralschmierung](#)
- 80 [Unterdruckanlage / Hydraulikanlage](#)
- 0 [WARTUNG](#)

13 [RIEMENTRIEB](#)

15 [ELEKTRIK, MOTOR](#)

20 [MOTORKÜHLUNG](#)

25 [KUPPLUNG](#)

32 [FEDERUNG, STOßDÄMPFER](#)

33 [VORDERACHSE](#)

40 [LAUFRÄDER, VERMESSUNG](#)

42 [BRESMEN](#)

- 46 [LENKUNG](#)
- 47 [KRAFTSTOFFANLAGE](#)
- 49 [ABGASANLAGE, ABGASREINIGUNG](#)
- 54 [ELEKTRISCHE AUSRÜSTUNG UND INSTRUMENTE](#)
- 82 [ELEKTRISCHE ANLAGE](#)

- 67 [FENSTER](#)
- 82 [ELEKTRIK AUFBAU, RADIO](#)
- 83 [HEIZUNG, LÜFTUNG, KLIMAAANLAGE](#)
- 88 [FAHRZEUG ANBAUTEILE](#)

22. LACKE & BETRIEBSSTOFFE

- 10 [LACKSTIFTE](#)
- 11 [SPRAYDOSEN](#)
- 13 [KLEBSTOFFE / PRIMER](#)
- 14 [ARBEITSMATERIAL KAROSSERIEREPARATUR](#)
- 17 [DICHTMITTEL UND KLEBER FÜR AGGREGAT](#)
- 18 [MOTORÖL](#)
- 19 [ABDICHTBAENDER / -SCHNÜRE](#)
- 20 [SERVICEMATERIAL MOTORKÜHLUNG](#)
- 21 [AUTOPFLEGE EXTERIEUR](#)
- 22 [AUTOPFLEGE INTERIEUR](#)
- 24 [FETTE / PASTEN](#)
- 26 [GETRIEBEOÖLE UND HYDRAULIKÖLE](#)
- 35 [HINTERACHSE](#)
- 42 [SERVICEMATERIAL BREMSEN](#)
- 47 [SERVICEMATERIAL KRAFTSTOFFANLAGE](#)
- 49 [SERVICEMATERIAL ABGASANLAGE](#)
- 54 [BATTERIESÄURE UND ELEKT. LEITUNGEN](#)
- 58 [WERKZEUG UND ZUBEHÖR](#)
- 67 [SERVICEMATERIAL EINGLASUNG](#)
- 72 [TÜREN](#)
- 77 [SERVICEMATERIAL VERDECK, SCHIEBEDACH](#)
- 83 [SERVICEMATERIAL KLIMAAANLAGE](#)

86 [SERVICEMATERIAL SCHEIBENWASCHANLAGE](#)

92 [ABDECKPLANEN](#)

Service A

Service B

Staubfilter erneuern

TIREFIT erneuern

Luftfiltereinsatz erneuern

Bremsflüssigkeit erneuern

Zündkerzen erneuern

Batterie im KEYLESS-GO Senderschlüssel erneuern

Ölservice Automatikgetriebe

Ölservice im Automatik- und Verteilergetriebe durch

Keilriemen erneuern bei Fzg. mit Einriementrieb

Generator tauschen

Starter tauschen

Elektrische Kühlmittelpumpe aus-, einbauen, n. B. €

Kühlmittel inklusive Frostschutzmittel erneuern

2 Stossdämpfer der Hinterachse erneuern

2 Dämpferbeine vorn erneuern

Federlenker rechts für Vorderachse erneuern

Federlenker links für Vorderachse erneuern

Federlenker beide für Vorderachse erneuern

Zugstrebe links der Vorderachse erneuern

Zugstrebe rechts der Vorderachse erneuern

Flüssigkeit der hydraulischen Bremsanlage erneuern

Bremsbeläge der Vorderachse erneuern, Faustsätze

Bremsbeläge der Hinterachse erneuern

Bremsbeläge der Vorder- und Hinterachse erneuern

Bremsscheiben und Bremsbeläge vorn erneuern

Internal

Bremsscheiben und Bremsbeläge hinten erneuern

Servolenkung tauschen

Kraftstoffpumpe erneuern

Bordnetzbatterie erneuern (nach Prüfung)

Leuchteinheit vorn links erneuern

Leuchteinheit vorn rechts erneuern

Leuchteinheit hinten links erneuern

Leuchteinheit hinten rechts erneuern

2 Wischerblätter für Frontscheibe erneuern

Wischerblatt für Heckscheibe erneuern

Frontscheibe erneuern

Verdampfer der Klimaanlage reinigen

Glas Aussenspiegel links erneuern

Glas Aussenspiegel rechts erneuern

Internal

hführen

erneuern

n
el

n, Faustsattel